


Vista detallada SRE 0031 TC



Nr.	Nombre Holding	EAN
1	Deposito extraíble de combustible PFHAL102093	8713508788265
2	Tapón depósito PFHAL100389	8713508770277
3	Tanque de combustible PFHAL100505	8713508774954
4	Filtro de combustible -F- PFHAL100225	8713508770314
5	Sensor nivel combustible PFHAL100506	8713508774961
6	Bomba inyeccion PFHAL100391	8713508770345
7	Vaporizador PFHAL100393	8713508770369
8	Tubería de descarga PFHAL100395	8713508770383
9	Bobina eléctrica PFHAL100398	8713508770413
11	Quemador PFHAL101229	8713508770437
12	Bujía de encendido PFHAL100399	8713508770451
13	Sensor llama PFHAL100507	8713508774978
14	Resistencia encendido PFHAL100402	8713508770482
15	Placa electronica con transformador PFHAL100521	8713508775111
16	Display de visualización PFHAL100515	8713508775050
19	Sensor de sobrecalentamiento PFHAL101815	8713508770611
20	Motor del ventilador PFHAL100409	8713508770628
21	Ventilador PFHAL103586	8713508005034
23	Sensor de temperatura ambiente PFHAL100512	8713508775029
24	Cable de alimentación PFHAL100523	8713508775135
27	Tapón de transporte -B- PFHAL100413	8713508770772